



1. Present Key Fob or enter Access Code and press **ENTER**

NOTE: Your Access Code should be 5-8 digits

3. Select either instant occupied or delayed occupied

- **Instant** will make the alarm go off as soon as the door is opened

- **Delayed** will give the person entering 30 seconds to disarm the system before setting the alarm off

4. Press **ENTER**

5. Select which partition you want to arm:

- **THIS PARTITION:** Arms the local partition

- **MY PARTITIONS:** Arms only the partitions your Access Code is programed to control

NOTE: See Partition list if not sure

6. Press **ENTER**

Note: The keypad will briefly display: **PLEASE WAIT WHILE ARMING..**

Putting your system in occupied mode means that all exterior doors will be armed but all interior motion detectors and audio sensors will be disarmed. This will allow you to stay in the building with out having to worry about someone coming in.